



Brief Instruction Guide

With the lockable tank lid the ORANKA beverage system offers you the highest product safety in accordance with food hygiene regulations. The patented locking system is made only from materials that can be hygienically cleaned in a dishwasher. The lid of the tank is locked by two safety bolts which can be slid under the edge of the tank.

The bolts close in this position with the sound of an audible click.

Please note the following steps when taking off the lid.

At www.oranka.com you can find more fruity information.

ORANKA. How practical.



1 Hold the inside of the lid's edge on the left and the right of the locking device with your index and middle finger. Now you can exert light pressure upon the locking device with your thumb.




2 Lay the magnetic key flat on the locking device.



3 After the magnetic bolts make a clicking sound, the safety bolts can now be pulled out.



4 Using your thumb and index finger pull out the locking device as far as it will go.



5 When the bolts are in this position you can take off the tank lid. Otherwise the instructions in the "ORANKA Eskimo Brief Instruction Guide" apply.



INFO If you have any questions regarding the patented ORANKA beverage system, please contact your personal ORANKA customer service representative. We are happy to help you.

ORANKA Brief Instruction Guide. Patented Magnetic Locking Device.